Bottom Paint Removal Decision Time

Is the money saved removing bottom paint yourself worth the time and effort?

By Darrell Nicholson

Published: June 1, 2022

Updated: December 27, 2023

Tempis fugit . . . times a-wastin' . . . fast flies the irreparable hour . . . However you choose to use your scarce time, we'll wager that you'd rather not spend it removing bottom paint. If you are an owner of an older boat with a decade of accumulated hard bottom paint that is flaking and cracking, now is a good time to start weighing your options for removing the old paint. Should you do it yourself, or hire the professionals—or a bit of both?



In past reports on removing bottom paint and barrier coats, we've explored various methods to do the job safely. But more recently, in the light of our depleting youthful vigor, a diminishing number of do-it-yourself boatyards, and the need for personal protection against fine particles and organic vapors, our enthusiasm do-it-yourself for a approach has steadily waned. Although substantial cost involved the renewing a bottom can be daunting, keep in mind that money and labor invested now will make subsequent

bottom jobs faster and cheaper, so there is a residual benefit. Provided you have access to a do-it-yourself yard, are serious about personal protection, and don't overextend the periods between reapplying bottom paint, your next decade of antifouling jobs could be do-it-yourself jobs.

As I recover from my own five-week long do-it-yourself paint removal project, I am reminded of a report by Ralph Naranjo, a former boatyard manager, marine safety expert, and *Practical Sailor* editor-at-large. Ralph was one of the last *Practical Sailor* testers to undertake a comprehensive test of coating removal methods and products (see "A Smorgasboard of Tools Required for the DIY Epoxy Barrier Coat Removal"). An excerpt from that report appears below ("Is It Worth It?"), along with Ralph's guide for estimating the amount of time required for any boat bottom project ("A Mathematical Decision-maker"). The DIY work calculator first appeared along with Ralph's report on Soda blasting, "Soda Blasting 101."

PS ESTI	MAI	E		
HULL STRIPPING & RECOATING				
TEM DESCRIPTION	ITEM AMT	SUB TOTALS		
EQUIPMENT		\$ 200		
TOOLS (IF RENTED)	\$200			
MATERIALS		\$2,241		
SANDING DISKS/SAND PAPER	\$125			
STRIPPER + PAPER/ COVER	\$420			
TAPE / PLASTIC	\$46			
BARRIER COATING	\$720			
BOTTOM PAINT	\$730			
LABOR		TOTAL		
MAN HOURS	140	140 hours		

This accounting of a **DIY** paint removal project on an Ericson 41 illustrates the importance of being generous in estimating the time required. Removing the bottom paint and barrier coat from the Ericson required 140 hours of actual work (see "Smorgasbord of Tools and Patience" are Required For DIY Epoxy Barrier Coat Removal").

Not long after Ralph's report, we went back into the boatyard and followed the bottom restoration of a Bristol 35.5 owned by the publisher. The Bristol, however, got the royal treatment, as the owner handed the project over to local professionals. The work and materials tallied in the table below are detailed in the report "Bottom Paint Makeover."

JOB / MATERIALS	TIME/QUANTITY	RATE*	AMOUNT
BOTTOM PREP AN	Control of the Contro	MAIL	AMOUNT
BOTTOM PAINT REMOVAL via sandblasting			\$2,000
SAND BOTTOM FAIR after blasting	6 hours	\$70	\$420
PREP BOTTOM FOR PAINT (Solvent wipe, tape waterline and mask shaft, zincs, etc)	4 hours	\$70	\$280
ROLL ON SEALANT COAT OF INTERPROTECT 2000	4 hours	\$70	\$280
FILL PITS/VOIDS WITH EPOXY	3 hours	\$70	\$210
SAND/FAIR EPOXY SMOOTH AND PREP FOR BARRIER COATS	5 hours	\$70	\$350
ROLL ON 4 COATS OF INTERPROTECT 2000 BARRIER COAT	16 hours	\$70	\$1,120
ROLL ON 2 COATS OF INTERLUX MICRON CSC ANTIFOULING	8 hours	\$70	\$560
BOTTOM PREP AND I	PAINT: MATERIALS		
INTERLUX INTERPROTECT 2000 GALLON KITS	5 gallons	\$127.80	\$639
INTERLUX MICRON CSC GALLON	2 gallons	\$250.26	\$500.52
INTERLUX WATERTITE EPOXY FILLER	1 liter	\$88.40	\$88.40
MASKING TAPE, ROLLERS, RAGS, GLOVES, ETC.	N/A	\$60	\$60
INTERLUX 216 AND 333 THINNERS	1 gallon	\$105.55	\$105.55
NEW BOOT ST	RIPE: LABOR		
TAPE AND SAND BOOT STRIPE; RETAPE; WIPE HULL CLEAN	5.5 hours	\$55	\$302.50
BRUSH ON 1 COAT INTERLUX BRIGHTSIDE POLYURETHANE	3.25 hours	\$55	\$178.75
SAND, CLEAN, AND BRUSH ON SECOND COAT	3.5 hours	\$55	\$192.50
RETAPE, SAND, CLEAN AND BRUSH ON THIRD COAT	3.5 hours	\$55	\$192.50
NEW BOOT STRIP	E: MATERIALS		
TAPE, BRUSHES, 220-GRIT SANDPAPER	N/A	\$30	\$30
INTERLUX BRIGHTSIDE POLYURETHANE	1 quart	\$34.99	\$34.99
GRAND TOTAL			\$7,544.7

The professional repair bill for the Bristol 35.5 "First Light" included a new barrier coat and paint (see "Bottom Paint Makeover")

If you are still in the water as you consider these options, we also have two helpful boatyard reports for those still choosing a yard "Do it Yourself Boatyards," and "Do it For Me Boatyards." Hopefully, you are already out sailing, and the next haulout is from your mind. But if you have decided to finally "bite the bullet," as Ralph puts it, I hope these reports can help. If you have specific questions about removing, choosing, or applying bottom paint, or if you have a boatyard to recommend, you can email us at practicalsailor@belvoir.com.

Is it Worth It?

At the conclusion of the paint removal ordeal (two full weeks), I asked myself, "Is this scale of commitment really what your typical DIYer should tackle?" The answer? An uncertain "maybe."

The job certainly can be turned over to pros and is a prime candidate for media blasting, but many yards don't want the airborne residue associated with the process. Tenting the boat or moving it into a building adds expense. And when all is said and done, the epoxy barrier coat is pretty immune to baking soda and may require blasting with a more aggressive grit that can tear into the gelcoat as well as remove the barrier coat. The slow and arduous combo of chemical stripping and sanding used to rid *Wind Shadow* of 26-year-old barrier coat left the gelcoat intact and provided an even surface over which to reapply the same epoxy system that had endured for over two decades.

Now that more and more barrier-coated boats are reaching the end of the paint's lifespan, owners will be looking for answers about what to do next. If there is a significant amount of interlaminate blistering in addition to barrier-coat blistering, it may be time for a "peel." This even more aggressive approach cuts all the way down to FRP laminate, removing barrier coat, gelcoat, and the pocked first layer of FRP laminate. Once the offending surface has been cleared away, the remedy is to re-laminate whatever schedule of material was removed. The new composite skin incorporates vinylester or epoxy resin, and the complete job includes re-fairing the surface, barrier coating, and finally bottom painting the underbody—a job that dwarfs the efforts bestowed on *Wind Shadow*, and one that will require professional intervention.

Those considering such a project as removing barrier coats should first evaluate their skill level, and then weigh the man-hours and cost of the project versus what it would cost to have a professional do it. In my case, removal options included subcontracting a soda blasting, which would cost \$2,500 and would only rid the hull of antifouling paint, not the failed epoxy barrier coat. A heavy- grit media blasting to remove the epoxy—along with much of the gelcoat—was considered too aggressive for this project, although we did use it in a subsequent bottom job on another test boat.



Even the most powerful vacuum won't get all the dust. A respirator and protective clothing, including a full Tyvek suit, is preferred over this casual approach. Closed-toe shoes—at a minimum—are a prerequisite for any boatyard work.

Leaving the whole job to the pros would've been pretty costly: A "peel" or blast approach and the follow-up fairing, resurfacing, epoxy barrier coats, and bottom paint would run about \$10,000-\$15,000. Rates, of course can vary by region. We paid just under \$8,000 to strip and refinish a Bristol 35.5 in Connecticut, and just under \$5,000 to strip and refinish the bottom of a 30-foot Yankee 30 in Florida. Both were media blasted (soda-blasted in Connecticut, wetabrasive blasted in Florida). In each of these two projects, the paint and barrier coat removal accounted for \$2,000 of the total cost.

Mathematical Decision Maker

So, how much work is it, really? An easy way to compute the do-it-yourself labor commitment involved is by timing how long it takes to scrape clean two 1-square-foot patches. The first is in the center of the least well-adhered paint; the second is in the midst of an intact portion of the bottom. Dry scrape each section with a thin-bladed putty knife and a sharp drag-type scraper, noting the time it takes to remove about 90 percent of the coating.



Flaking paint can require extensive sanding in order to prepare for repainting.

Next, estimate the percentage for the bottom that should be dubbed easy to scrape paint versus areas where the antifouling is stuck like glue. Finally, you need to roughly calculate the square footage of wetted surface area (WSA) that comprises the underbody. This is by no means an ordeal that requires advanced geometry. It's a rudimentary calculation that requires only three bits of information (waterline length [Lwl], maximum waterline beam [Bwl] and draft [T]). The user-friendly formula (WSA = Lwl x (Bwl+ T) applies to most heavy displacement cruising hulls. Multiply by 0.75 for medium-displacement vessels and 0.5 for light-displacement boats. This oversimplification of wetted surface calculation would provoke a scolding from David W. Taylor, William Froude, and other dons of naval architecture, but for a paint removal estimate, it works just fine.

Finally, take the results of the calculation and divvy it up according to the proportion of easy versus difficult regions of paint removal. For example, if only 15 percent of the bottom is cracked and peeling, and the removal time per square foot in this region is 30 seconds—as compared to four minutes per square foot in the well-adhered section—the ratio is by no means encouraging. Applying the ratio to the wetted surface calculation drives home the level of paint scraping required.



When sanding bottom paint, use only NIOSH-rated high efficiency filters (see "The Best Respirators for the Boatyard". Practical Sailor September September 2017). Do not use disposable fabric masks – they do not provide the same level of protection. Goggles and a hood further increases protection, but they can be hard to bear if it is hot.

When sanding bottom paint, use only NIOSH-rated high efficiency filters (see "The Best Respirators for the Boatyard". Practical Sailor September 2017). Do not use disposable fabric masks – they do not provide the same level of protection. Goggles and a hood further increases protection, but they can be hard to bear if it is hot.

Let's assume that the vessel has a 30-foot waterline, 6-foot draft, a waterline beam of 10 feet, and is a medium-displacement vessel. Our fuzzy math for a medium-displacement sailboat fills in the WSA equation as follows: $WSA = 30 \times (10 + 6) \times (.75)$, and the result is 360 square feet.

Next comes the all-important apportionment of easy versus difficult paint removal. In this case, 85 percent falls into the tough-going regime that equates to four minutes of toil per square foot $(0.85 \times 360 \times 4 = 1,224 \text{ minutes})$. Add in the easy scraping $(0.15 \times 360 \times 0.5 = 27 \text{ minutes})$, and the result is 1,251 minutes, or just under 21 hours of serious scraping. This is unequivocal arm-in-action time, and the ride to the boatyard, coffee breaks, and chats with sistership owners, stops the clock.

This method to estimating work on the hull bottom could also be applied to a topside or deck project. Just be sure include some awkward work areas in your "sample" panels for estimating the total time required. Removing paint in some areas—cockpit corners, or near trim—can require two to three times more work than flat areas of the hull, and this needs to be taken into account.

Chemical paint removers, a large crew, or true friends can soften the blow, and so can a more deteriorated surface. If 70 percent of the bottom paint has a cornflake-like look, it will allow a thin bladed putty knife to effortlessly separate it from the hull skin, and a very different labor

picture arises. Run the numbers, and you'll find that in this scenario, 9.3 hours of toil would strip away the residue. In short, it's not the bad spots you need to worry about, it's where the paint looks good that causes all the problems. This is why procrastination rules, and we tend to postpone bottom paint removal in favor of spot prepping and feathering in the bad spots. At some point, it's time to bite the bullet and tackle what's been pushed down the road.

Darrell Nicholson

Practical Sailor has been independently testing and reporting on sailboats and sailing gear for more than 45 years. Supported entirely by subscribers, Practical Sailor accepts no advertising. Its independent tests are carried out by experienced sailors and marine industry professionals dedicated to providing objective evaluation and reporting about boats, gear, and the skills required to cross oceans. Practical Sailor is edited by Darrell Nicholson, a long-time liveaboard sailor and trans-Pacific cruiser who has been director of Belvoir Media Group's marine division since 2005. He holds a U.S. Coast Guard 100-ton Master license, has logged tens of thousands of miles in three oceans, and has skippered everything from pilot boats to day charter cats. His weekly blog Inside Practical Sailor offers an inside look at current research and gear tests at Practical Sailor, while his award-winning column, "Rhumb Lines," tracks boating trends and reflects upon the sailing life. He sails a Sparkman & Stephens-designed Yankee 30 out of St. Petersburg, Florida. You can reach him by email at practicalsailor@belvoir.com.